

1. Overview

Quick Start Guid

WL Series

Version: 1.2

	2.8 Inch TFT LCD 0 0 0 0 4 Indicator 0 0 0 0 4 Keypad 0 0 0 0 0 Fingerprint Sensor			
2. Installation				We bet met
	STEP 1	STEP 2	STEP 3	ceil may
	Drill holes in wall and fix the back plate as shown.	Hold the device and fix it with the upper hook first and then follow the next step.	Finally, after fixing the upper hook, tighten screw at the back of the device.	Hotsp
				We the met neg
stency between				



N Mode

シ

recommend that the indoor communication distance etween the device and the router should be within 20 eters. The number, thickness and location of walls, ilings, or other objects between device and the router ay affect the Wi-Fi signal.

pot Mode



e recommend that the communication distance between ne device and the mobile phone should be within 15 eters. Complex environmental condition may have a egative effect on range.

2

Due to regular upgrades of systems and products, ZKTeco could not guarantee exact consis the actual product and the written information in this manual.



device to USB disk or SD card. Download User : Download the full user information and \checkmark ingerprint data to USB disk or SD card. Note: SD card is an optional feature.

No: Device number.

Download Attlog: Download the full attendance data from


Press **M/OK** on the initial interface. Select Data Mqt. and press M/OK. Select Download Attlog/User then press M/OK.

2.Mobile APP download \bigstar (\bigstar stands for optional feature)



Press **M/OK** on the initial interface then select System and press M/OK. and press M/OK. Press ▲/▼ to select Ethernet then select PC Connection and press M/OK.

Press $\triangleleft / \triangleright$ to Select Wi-Fi setting select Network Mode and press M/OK then then select **hotspot** set hotspot configuration and



On the Application, administrators can manager employee shifts and download monthly attendance report. Just add device and shake mobile to download data. It's very convenient for a simply attendance company or shops without PC Requirement.

8. Reset Opts.

To restore all the setting of the device as default, including communication option, system option, shift option and so on.

6

System					
System	Update firmware				
Date/Time	Ethernet				
Auto Switch	Reset Opts.				
DST	Alg. Ver.				
Bell					

Press M/OK on the initial interface. Select **System** and press M/OK.Press ▲/▼ to select Reset Opts. Press M/OK to reset. Press ESC to exit.

Notes:

After restoring factory reset, system parameters, timer state switch, alarm settings, DST, Wi-Fi settings, attendance parameters, shift, etc. will be restored to default values. The user data and attendance records will remain unchanged.

9. Algorithm Version Switching

The device supports fingerprint algorithm version switching between ZKFinger VX10.0 and ZKFinger VX13.0.



Note: Every time a user switches the fingerprint algorithm version, the device will delete the data and reboot

Press **M/OK** on the initial interface. Select System and press M/OK.Press ▲/▼ to select Alg. Ver.. Press M/OK to switch. After it prompts "Operating successfully, restart device!", press M/OK to restart the device.




press M/OK.

7

4. Add User

Press **M/OK** on the initial interface. Select **User** and press M/OK. Select Add user and press M/OK.



ID: Enter the user ID. Name: Use T9 to enter name(supports 23-character names). **FP**: Place your finger on the fingerprint collector for three consecutive times correctly until enrollment succeeds. **PWD**: Enter a 1 to 8 digit password Dept: Select department. Purview: Select purview(User and Administrator).

Finally, press ▲/▼to select M/OK and press M/OK. A new user will be added.

5. T9 Input

In the text input box such as Name, Dept., etc., press button M/OK to switch to T9 input method.

Edit user

	Edit user			
ID	1		ID	1
Name			Name	
FP	Enroll FP	FP Cnt:0	FP	
PWD	Enroll PWD		PWD]
[An]			[An]	A

		ID	1
		Name	Angel
Enroll FP	FP Cnt:0	FP	Enroll FP
Enroll PWD		PWD	Enroll PWD
B C		[An]	

to enable the T9 input method.

Press the [M/OK] key Press ∇/A button to While in Symbol mode, press $\triangleleft/\triangleright$ button switch English or Symbol mode. to see more symbol. 3

6. Wi-Fi Setting

Our terminal is equipped with Wi-Fi. It supports either built-in or external Wi-Fi module to implement wireless data transmission over the Wi-Fi.



Press **M/OK** on the initial interface. Select System and press M/OK.Press \blacktriangle/∇ to select Ethernet. Select Wi-Fi setting and press M/OK to enable the Wi-Fi setting method.

network, enter to Wi-Fi (OK).

Press ∇/A to select Select the connected network and press password to connect M/OK, you may see the IP address of the connected network.

7. USB Download/Mobile APP Download

The device allows downloading user data and attendance data to a USB flash drive or mobile phone so that the data can be processed properly by attendance software.

1.USB download

Insert an USB host or SD card into the USB host or SD card slot on the device.

4

10. Technical Tips

1. Setting up Multiple Super Administrators. Two or more administrators are recommended to set up to ensure that relevant device operations are handled in a timely manner even if an administrator is absent.

2. Difficulties in Fingerprint Matching When a user presses a finger on the device, the device prompts "Please try again ".

- Verify whether the fingerprint has been enrolled on the device or not.
- Try 1:1 verification. Specifically, enter the user ID and then press the registered finger on the device to increase the matching success rate.
- Enroll two fingerprints with high quality again.

ZKTeco Industrial Park, No. 32, Industrial Road, Tangxia Town, Dongguan, China. Phone : +86 769 - 82109991 +86755-89602394 Fax www.zkteco.com

